

05

	HEX		HEX
	FE		FE
	05		05
	00		00
	00		00
	FF		FF
	00		00
CRC	98	CRC	98
CRC	35	CRC	35

15 HEX 0F


	HEX		HEX
	FE		FE
	0F		0F
	00		00
	00		00
	00		00
	10		10
(8)	02	CRC	40
	FF	CRC	08
	00		
CRC	E6		
CRC	24		

-
-
-

-







02

	HEX		HEX
	FE		FE
	02		02
	00	(8)	02
	00		00
	00		00
	10	CRC	AD
CRC	6D	CRC	AC
CRC	C9		

04

	HEX		HEX
	FE		FE
	04		04
	00	(1)	20
	00	1	00
	00	1	00
	10	
CRC	E5	16	00
CRC	C9	16	00
		CRC	88
		CRC	62

03

	HEX		HEX

	FE		FE
	03		03
	01	(1)	20
	2C	1	00
	00	1	00
	10	
CRC	90	16	00
CRC	3C	16	00
		CRC	88
		CRC	62

06

	HEX		HEX
	FE		FE
	06		06
	00		00
	00		00
	01		01
	90		90
CRC	9C	CRC	9C
CRC	39	CRC	39

16 HEX 10

	HEX		HEX
	FE		FE
	10		10
	00		00
	00		00
	00		00
	04		04

2	08	CRC	D5
	01	CRC	C5
	90		
	01		
	90		
	01		
	90		
	01		
	90		
CRC	99		
CRC	1E		