

232- 4 5/422



2016 0

.....	1
.....	1
.....	1
.....	2
.....	3
.....	4

-
-
- RS232 RS485 RS422
- 485

- RS232-485/422
-




1	GND	GND
2	VCC	7~30V DC
3	N/C	
4	N/C	
5	N/C	
6	GND	GND

7	RXD-	422	-	
8	RXD+	422	+	
9	T/B-	422	-	485B-
10	T/A+	422	+	485A+
11	DB9	232		
12	RS232	232		

RS232
 RS485
 RS422

DB9
 A+ B-



7-30V DC



400-6688-400

<https://www.juyingele.com/download/JYDANSoftware.zip>

www.juyingele.com

<https://www.juyingele.com/download/JYNetConfig.zip>

